



## Flash Tube Replacement Instructions

L I G H T R E I M

1. Remove the plastic cover from the strobe.
2. Remove the Pyrex cover from the strobe.
3. Using a soft tissue (to avoid any fingerprints on the bulb) remove the modeling light by pulling up gently .
4. Locate the end of the wire that is wound around the support post and the flash tube.
5. Unwind the wire holding the flash tube in place.
6. Lift the flash tube connectors up evenly by placing a pencil under the flash tube.
7. Gently lift up and the tube with the brass connectors will pull out of the strobe.
8. Again, use a tissue to take the flash tube out to avoid any finger prints.
9. Install the new tube while holding it with a tissue. Align the brass connectors in the holes and press down evenly until they are pushed in all the way.
10. Repeat in reverse steps 5 through 1.

